



[www.jgdesignandfab.com](http://www.jgdesignandfab.com)

Follow us on Instagram

@jgdesign\_fab

(805) 765-0021

### **54 Chevy Tail light fuel fill install instructions**

-Remove the bulbs from your driver's side tail light. Take note as to which is a brake light and which is the reverse light.

-Remove driver's side tail light bezel / lens assembly from body. (4 ¼ threaded studs or 7/16 nuts)

-Once light out of vehicle, unbolt rear lens housing from bezel. \*While doing this, hold housing with lens' facing down to keep them in place easier.

-Install JG tail light assembly to bezel using stock gasket with lens' in place using hardware provided. (#6 x 32 button heads)

\*We recommend a dab of locktight on each bolt to ensure they don't back out.\*

-The assembly is now ready to bolt into body. The assembly goes through the taillight opening and bolts to the inside of the body.

\*You may have to clearance the pinch seam on the inside of the vehicle to allow the pivot assembly to bolt up flush to the body.\*

-We provide half the mounting hardware (2 bolts) with a washer for the bolt side and for the nut side of the hardware. The other 2 bolts have 3 washers. This is to shim the assembly further into the body to align the bezel with the body if needed.

-The fuel filler neck bracket bolts to the rear side of the lower hardware. Bolt in place once bracket alignment is finalized.

-Now that the bracket is bolted in place and functional, take the provided light sockets and splice the wiring into the existing brake and reverse lights. Route the wiring down the pivot arm and zip tie in place.

-Cycle up and down a few times to ensure the wiring doesn't pull out of the sockets.

